


How to use your Polaroid ND Filters

These filters are designed to fit over the film in a Polaroid 600-sized film pack. They are placed on top of the film pack's darkslide, and stay in place once the film has been inserted and the darkslide has been ejected. To fit your filter, carefully follow the diagram below:



1) Hold the 600 film pack so the darkslide is upside down.

2) Place the Filter over the film pack with the three tabs facing upward.

3) Gently press all the central tabs down so they 'pop' under the plastic frame.

4) Important! Leave the upper left and right tabs outside the plastic frame.

Film compatibility:

These filters are sized for use with Polaroid 600 film packs - both the classic 10-frame style and newer 8-frame style. Should you wish, the filters can also be used with SX-70 film packs and the newer i-Type film.

Technical data:

These filters are cut from LEE Filters® gel. Two versions exist, providing 1-stop or 2-stops attenuation, and identified by a coloured dot sticker.

Green dot: 1-Stop. Factor ND3. Optical Density 0.3. Transmittance 50%.

Blue dot: 2-Stop. Factor ND4. Optical Density 0.6. Transmittance 25%.

Packaging disposal and recycling:

The cardboard 'topper' and tissue paper are classed as 'PAP 21' and can be placed in your household recycling (UK).

The Polythene sleeve can store your filters when they are not in use. When it's no longer needed, the sleeve material can be recycled with other bags at supermarkets. Local kerbside collection rules may vary (UK).

The filter material is classed as DMR (Dry Mixed Recyclables). Some recyclers happily accept it, others won't. It's probably best to check your local kerbside collection rules. We'll post any updates to <https://filmcameras.uk/600nd>.

Problems?

Firstly, if the filter is ejected with the darkslide, make sure the two outer tabs are not inserted under the plastic frame. If this happens you'll need to reinser your darkslide in pitch-black conditions and try again.

If you have any other issues or questions, please email: support@filmcameras.uk or reach out on the Social links below: